



Service Bulletin

Priority: **Medium**

No 10 2006-02-13

General maintenance

System Applicability: MARINFLOC CD units

Important:

- According to Marinfloc Operators Manual for CD models under “Maintenance” it is described how to perform a steam regeneration of the filter material by increasing the temperature on the back flush water heater to 99°C. As it is possible to “push” out filter material from the filter step, down to the bilge water tank if the temperature rises to 100°C, **it is very important that the temperature of the regeneration water never exceeds 90°C**

All the previous service bulletins and other important information, as e.g. updated lists of approved chemical and flocculants, can be found on our website: www.marinfloc.com

Don't hesitate to contact us if any questions or problems!

You can easily reach us by phone: +46 (0)304-606 300, fax +46-(0)304-100 51 or via e-mail to service@marinfloc.com.

-Our mission is clear ~ a clean sea!-

2006-02-13 PL

Adress/Address:
Industrivägen 10
SE-472 95 Varekil
Sverige/Sweden

Tel: +46 (0)304 -606 300
Fax: +46 (0)304 -100 51
E-mail: marinfloc@marinfloc.com
Internet: www.marinfloc.com

Org nr/Corporate identity No:
556520-6363
Momsregnr/VAT No:
SE556520636301